


## NOTES:

1. DIG A 6"x6" TRENCH ALONG THE INTENDED FENCE LINE.
2. DRIVE ALL POSTS INTO THE GROUND AT THE DOWNHILL SIDE OF THE TRENCH.
3. LAY OUT SILT FENCE ON THE UPHILL SIDE ALONG THE FENCE LINE, AND BACK FILL.
4. WOOD POSTS MAY BE SPACED UP TO 5 FEET APART. STEEL POSTS MAY BE SPACED UP TO 6 FEET APART
5. REMOVE SILT FENCE AFTER TURF IS ESTABLISHED.



STANDARD DETAILS  
SILT FENCE DETAIL  
CITY OF PLYMOUTH

PUBLISHED  
3-23

CITY PL. NO.  
ST-18  
REVISED 1-20